AUXILIARY HYDRAULIC SELECTOR - (One Handle) - A three position handle that controls the auxiliary pump selector valve located in the L. H. wheel well. This valve permits the pump to furnish pressure to the various systems as called for by the handle. These handle positions are "BRAKE", which is the normal flight position, "SYSTEM" and "ACCUMULATOR". In the "BRAKE" position the auxiliary pump also furnishes pressure to the cargo doors.